

# Instructions Sheet

## DOWNHOLE SOLUTIONS CEMENT BAILER KIT

### Step 1

**Open Bucket  
Remove**

- Two**     ½ Gallon Mix fluids Containers
- One**     24 oz RT 40L Retarder Jug
- One**     Plastic bag with Dry blend Cement
- One**     60 ml Syringe

### Step 2

**Pour Both Mix Fluid Containers into mixing pail.  
If needed add Liquid Retarder RT40L into the Mix Fluid per  
Temperature Chart using the 60ml syringe provided. Stir for +3 minutes.**

Temperature	Deg F	<u>RT40L Retarder (cc's)</u>
	<b>80 - 100</b>	<b>None</b>
	<b>101 - 110</b>	<b>4 cc's</b>
	<b>111 - 120</b>	<b>5 cc's</b>
	<b>121 - 130</b>	<b>7 cc's</b>
	<b>131 - 140</b>	<b>9 cc's</b>
	<b>141 - 150</b>	<b>10 cc's</b>
	<b>151 - 160</b>	<b>10 cc's</b>
	<b>161 - 170</b>	<b>11 cc's</b>
	<b>171 - 180</b>	<b>12 cc's</b>
	<b>181 - 190</b>	<b>13 cc's</b>
	<b>191 - 200</b>	<b>14 cc's</b>
	<b>201 - 210</b>	<b>17 cc's</b>
	<b>211 - 220</b>	<b>24 cc's</b>
	<b>221 - 230</b>	<b>30 cc's</b>
	<b>231 - 240</b>	<b>41 cc's</b>
	<b>241 - 250</b>	<b>53 cc's</b>
	<b>251 - 260</b>	<b>67 cc's</b>
	<b>261 - 270</b>	<b>84 cc's</b>
	<b>271 - 280</b>	<b>101 cc's</b>
	<b>281 - 290</b>	<b>117 cc's</b>
	<b>291 - 300</b>	<b>135 cc's</b>

### Step 3

**Add Plastic bag of dry blend slowly until thoroughly mixed. Normally 5-10 minutes.**